

Carbon Sample Collection Instructions

The following instructions pertain to the collection of carbon samples for analysis to be completed at Engineering Performance Solutions (EPS).

Instructions:

1. Fill plastic container (no Ziploc bags) with 200g-500g of **DRY** carbon.
2. Label the container with sample ID
3. Fill out chain of custody
4. Samples should be shipped overnight to EPS at:

**Engineering Performance Solutions
3161 St. Johns Bluff Road S. Suite 3
Jacksonville, FL 32226**

Important: EPS does NOT accept Saturday deliveries.

For additional information call:

Christine Valcarce, Ph.D.

904-645-7775