

Shipping Instructions

1. Fill Ziploc bags provided with ice.
2. Rinse carboy with sample water before filling to top.
3. Fill carboy with sample and secure lid with tape.
4. Place carboy in cooler then place Ziploc bag with ice in carboy.
5. Include instruction sheet with Name, Date and Test to perform.
6. Secure lid of cooler with tape and ship overnight to:

**Engineering Performance Solutions
3161 St. Johns Bluff Road S. Suite 3
Jacksonville, FL 32246**

Important: EPS does NOT accept Saturday deliveries

If you have any questions call:
Christine Valcarce, Ph.D.
904-645-7775